

GAVAZZI TESSUTI TECNICI S.p.A. s.u.
Sede centrale / Headquarter
Via Gavazzi, 3
23801 Calolziocorte (LC), Italia
Tel. +39 0341 641051 | Fax +39 0341 633466
info@gavazzispa.it | www.gavazzispa.it

INSTALLATION METHOD GAVATEX CLASS

WARNINGS

Check the product before application, any defects must be reported immediately while continuing the installation implies acceptance of the product on adjacent surfaces use only products with the same batch number printed on the package.

SUBSTRATE PREPARATION:

Surfaces must be dry, clean and stable, remove old wallpapers that may detach for highly absorbent surfaces, apply a primer coat with GAVADES adhesive diluted with 50%-70% water.

ADHESION:

Prepare the fabric panels always allowing 5-10 cm more than the wall height to obtain Class B-s1,d0 fire reaction spread evenly with a roller GAVADES adhesive diluted with 10% water for a better aesthetic effect, apply on the dry fabric a second coat of GAVADES adhesive diluted with 30% water consumption 200-350 g/m² to obtain Class A1 fire reaction mix the cementitious adhesive KERABOND white – Mapei with 35% water until a homogeneous paste is obtained using a mixer to avoid lumps, let it rest for 5-10 minutes and mix again, then spread evenly with a notched trowel (fine or medium, tooth n°2 to n°4) consumption 1100 g/m² ±10%, apply the fabric and press with a spatula from the center to the edges to expel any air bubbles and ensure perfect adhesion place the panels edge to edge without overlapping trim the excess fabric with a utility knife.

FINISHING AND PAINTING:

Let dry and proceed with roller painting the first and second coat it is advisable to use washable acrylic paints or water-based enamels glossy or matte appropriate color choices and different finishing techniques offer a wide range of decorative effects that harmonize well in any setting.