

GAVAZZI TESSUTI TECNICI S.p.A. s.u.
Sede centrale / Headquarter
Via Gavazzi, 3
23801 Calolziocorte (LC), Italia
Tel. +39 0341 641051 | Fax +39 0341 633466
info@gavazzispa.it | www.gavazzispa.it

INSTALLATION METHOD GAVATEX FULL

WARNINGS

Check the product before application, any defects must be reported immediately while continuing the installation implies acceptance of the product on adjacent surfaces use only products with the same batch number printed on the package.

SUBSTRATE PREPARATION:

Surfaces must be dry, clean and stable remove old wallpapers that may detach, for highly absorbent surfaces, apply a primer coat with GAVADES adhesive diluted with 50%-70% water.

ADHESION:

Prepare the fabric panels always allowing 5-10 cm more than the wall height GAVATEX FULL falls under class B s1, d0 fire reaction insert and slide the fabric through the wallpaper tool Water-Active and fold it onto the tool surface, the layer of adhesive on the back of the fabric reactivates in about one minute while for ceiling applications, 2-3 minutes of immersion are required, apply the fabric and press with a spatula from the center to the edges to expel any air bubbles and ensure perfect adhesion place the panels edge to edge without overlapping and trim the excess fabric with a utility knife.

FINISHING AND PAINTING:

Let dry and proceed with roller painting the first and second coat for pre-painted FULL wall coverings usually one coat with a glossy, satin or matte paint, white or light colors is sufficient it is advisable to use washable acrylic paints or water-based enamels glossy or matte appropriate color choices and different finishing techniques offer a wide range of decorative effects that harmonize well in any setting.