

GAVAZZI TESSUTI TECNICI S.p.A. s.u.
Sede centrale / Headquarter
Via Gavazzi, 3
23801 Calolziocorte (LC), Italia
Tel. +39 0341 641051 | Fax +39 0341 633466
info@gavazzispa.it | www.gavazzispa.it

INSTALLATION METHOD GAVATEX on 3Demand

WARNINGS

Check the product before application; any defects must be promptly reported, while continuing the installation implies acceptance of the product. On adjacent surfaces, use exclusively products with the same batch number printed on the packaging.

SUBSTRATE PREPARATION:

Surfaces must be dry, clean, and stable. Remove old wallpapers that could detach. For particularly absorbent surfaces, apply a primer coat with GAVADES adhesive diluted with 50%–70% water.

GLUING:

Prepare the fabric sheets, always allowing an extra 5–10 cm compared to the wall height. To achieve Class B-s1,d0 reaction to fire:

Apply evenly with a roller GAVADES diluted with 10% water. For a better aesthetic effect, apply a second coat of GAVADES adhesive diluted with 30% water on the dry fabric. Consumption 200–350 g/m².

To achieve Class A1 reaction to fire:

Mix the cementitious adhesive KERABOND white – Mapei with 35% water until a homogeneous mixture is obtained, using a mixer to avoid the formation of lumps. Let it rest for 5–10 minutes and mix again, then spread it evenly with a notched trowel (fine or medium, notch from no. 2 to no. 4). Consumption 1100 g/m² ±10%. Apply the fabric and press with a spatula from the center towards the edges to remove any air bubbles and to ensure perfect adhesion. Place the sheets side by side without overlapping and trim the excess fabric with a cutter.

FINISHING AND PAINTING:

Allow to dry and proceed with roller application of the first and second coat of paint. It is recommended to use washable acrylic paints or glossy or matte water-based enamels. Appropriate color choices and different finishing techniques offer a wide range of decorative effects that harmonize well in any environment.
