

6" Installation Instructions



IMPORTANT Read all instructions before installing fixtures. Keep for future reference.
SAFETY For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.
WARNING Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

WARNING:

- Risk of fire or electric shock. Install this kit only in the luminaire that has the construction features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.
- Do not make or alter any open holes in an enclosure of wiring or electrical components during installation.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- This retrofit kit is accepted as a component of a luminaire where the suitability of the combination shall be determined by authorities having jurisdiction. Product must be installed by a qualified electrician in accordance with the applicable and appropriate electrical codes. The installation guide does not provide local or national regulations for electrical installations.

1. Disconnect all power prior to installation.
2. Remove the existing trim and bulb to gain access to the socket.
3. Screw in the E26 socket adapter into the open socket (Fig. 1).
4. Plug in the quick connector (Fig. 2).
5. Once connector is attached, gently push trim into fixture opening until flush with ceiling (Fig. 3).
6. For 4" downlights, unscrew and adjust the plate inward or outward for 4" diameter.

INSTALLATION

