




Cubo Washplane

Installation
Care & Maintenance
Warranty



Plumbers - Please leave this booklet with the homeowner

Please inspect items upon delivery.


If you believe there is a fault, damage or the item is incorrect, contact the place of purchase immediately, DO NOT PROCEED WITH INSTALLATION.

ONCE INSTALLED NO CLAIM OF DAMAGE WILL BE ACCEPTED

Omvivo allow 7 days from receipt of goods for notification of any discrepancies in good received.

CUBO WASHPLANE ASSEMBLY LIST

Figure 1.



*Cubo Washplane & waste assembly are indicative

Cubo Washplane Warranty

Cubo washplanes are covered by a

5 YEAR WARRANTY - DOMESTIC USE

This warranty covers faults in the product construction, material and assembly. Products which are within 5 years material or assembly, will be repaired or exchanged with an equivalent product free of charge.

LABOUR AND SPARE PARTS

A 12 month warranty over spare parts and labour will cover spare parts which are within 1 year from the date of assembly, will be replaced free of charge.

WARRANTY CONDITIONS

This warranty will apply only under all of the following conditions:

- The item has been installed by a licensed plumber
- The item has been installed for and subjected to domestic residential use only
- Failure is due to a fault in the manufacture of the product
- Proof of purchase (including date of purchase) is provided
- The installation of the product is in accordance with the instructions provided

This warranty does not include faults caused by:

- Unsuitable or improper use
- Incorrect installation or installation that is not in accordance with the instructions provided
- Installation or part installation by the purchaser or any person other than a LICENSED PLUMBER
- Normal wear and tear
- Inadequate or complete lack of maintenance
- Chemical, electrochemical or electrical influences
- Harsh detergents or abrasive cleaners used on product finishes
- Failure of stone material. Stone is a natural material and as such Omvivo will not warrant against the failure of the natural stone

PLEASE NOTE: The manufacturer will not be liable for the cost of installation or removal of any unit and the warranty will be voided if damage occurred during or installed.

1 YEAR WARRANTY - COMMERCIAL USE

“Commercial” use is all use other than for normal domestic residential purposes, including use in non-business places as in public buildings, schools, sports centers and in establishments that contain private bathrooms with high frequency of use by many individuals such as hotels, motels, retirement villages and hospitals.

The commercial warranty covers this product against manufacturing faults in the construction, material and assembly of both the finished product and any spare parts for a period of 1 year from the date of purchase. Products and spare parts, which are found upon inspection by an authorized representative to be defective in construction, material or assembly will be repaired or exchanged free of charge. The warranty conditions and exclusions, which apply to the domestic use warranty, also apply to this commercial warranty.

EXCLUSIONS

To the fullest extent permitted by law, the manufacturer excludes all liability for damage or injury to any person, damage to any property and any indirect consequential or other loss or damage.

CLAIM PROCEDURE

For all warranty queries, customers are to contact the branch where the product was purchased. These details can be found on your purchase invoice.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be acceptable quality and the failure does not amount to a major failure.

Cubo Washplane Care & Maintenance

Begin by removing the Cubo Washplane waste cover with a suction cup/s.

Always start your cleaning routine with the basic clean and move to a deep clean is necessary.

Basic Clean: Spills should be cleaned promptly. Clean with a mild detergent or soapy water and a soft, sponge or non-scratch scourer*¹.

Deep Clean: For a deep clean and to remove cosmetics, ink and other colour agents that may leave marks on the surface use a diluted very mild abrasive cleaner* with a soft cloth in light circular motions. For stubborn marks or staining a light buff in circular motions using diluted very mild abrasive* cleaner with non-scratch scourer *¹ will generally restore the finish.

Intense Clean/Repair: For extreme marks and light scratches a very light buff in circular motions using the fine grade sand/glass paper¹ will restore the surface. A heavier grade of sandpaper will scratch the surface, which can be removed by then using a light sand paper.

Softskin Basic Clean: Clean with warm soapy water or non-acidic, non-abrasive, mild detergent and soft cloth. Finish by cleaning off detergents with a soft wet cloth and towel dry.

Important notes:

For best results finish by wiping surface clean of all detergents and dry with a soft clean cloth.

Regular cleaning will assist to keep your solid surface and cabinetry looking fantastic and reduce wear and dirt build up.

For consistent appearance with your solid surface, it is best to give the entire surface of the product the same clean/sand. Avoid applying excessive pressure on clean/rub the same area for a prolonged period of time, unless repairing a scratch or damage.

Never use sharp products such as steel wool or aggressive, commercial grade / strong cleaners or chemicals (e.g. acetone, Trichloroethylene, acids and caustics soda) as these may damage and scratch the surface.

Only use your Vision basin cleaning instructions on your Vision basin as these cleaning methods may cause damage to other products, materials and finishes which will not be covered by your warranty.

* Always test 'non-scratch' and 'mild abrasive' products in a non-conspicuous area first to ensure suitability as brands can differ.

¹Your washplane has been supplied with a white non-scratch scourer and a fine grade sanding pad.

CUBO WASHPLANE INSTALLATION

1. Mark mounting bolt positions on wall ensuring they are level and at correct height. Ensure that the mounting wall surface is flat, smooth and free of debris. Washplane includes standard Omvivo fixing kit and wall brackets (See figure 2), these should only be used where appropriate. It is the responsibility of the installer to determine appropriate fixings, ensure wall is suitable and studs/noggins are in appropriate locations (See figure 3.1 & 3.2).
2. Check the correct placement of the washplane by holding washplane in position on wall aligning mounting holes to wall markings. Brackets should be spaced evenly to distribute the weight of the washplane.
3. Install fixing bolts and supplied brackets to wall and mount the washplane onto the brackets and bolts threads. Mount the plastic washers over the bolt threads by pressing them into the mounting holes in washplane. Install and tighten fixing nuts on the fixing bolt thread. Use 15mm screws to secure washplane to brackets through 18mm substrate secured under washplane.
IMPORTANT: Washplane must be supported by installer until all brackets, fixing bolts and nuts are secure to take the load of the washplane.
4. Once washplane is safely secured to wall, complete tapware installation.
5. Place waste through the washplane with seals in place, hand-tighten lock-nut to secure waste in basin. (See figure 5).
6. Once waste has been secured, connect trap and other hardware as necessary.
7. Once Cubo washplane installation is complete, washplane waste cover can be installed by carefully placing it inside the washplane using a suction cup/s.

Figure 2.


Standard Fixings

*Basin fixing bolts are indicative



Standard Wall Fixing Bracket

*Bracket diagram is indicative



Installer to determine appropriate fixing bolts on installation of washplane to wall surface.

Note: Cubo Washplane = 1 x set of fixing kit

Figure 3.1
Washplane Mounting bolt alignment




Figure 3.2
Washplane installation to wall




Figure 4.
Spout & Mixer Installation
***Tapware and waste assembly are indicative**




Figure 5.
Bracket spacing
***Spacing is indicative**




Figure 6.
***Waste is indicative**

