

Jacuzzi[®]Lights Troubleshooting Guide





Do a J-68 Reset. If that does not work, replace the circuit board.