


CLEARRAY® Not Working Troubleshooting Guide

Verify that the CLEARRAY® system should be running before proceeding (no error message, not in summer logic).

Note: The CLEARRAY® only runs in conjunction with the circulation pump.

Diagnostic Tools: Clamp-on ammeter, voltmeter

Suggested Spare Parts: CLEARRAY® ballast, UV bulb, PWA



Note: A solid power light indicates that the CLEARRAY® system is being provided power and should always be on. A solid UV bulb indicator light indicates that the UV bulb is activated.