

Watt & CCT Selection

2X2 WATT

40W | 30W | 20W

Pre-Set: 40W

2X4 WATT

50W | 40W | 30W

Pre-Set: 50W

Watt Adjustable

2x2 size: 20W/30W/40W (Pre set 40W)

2x4 size: 30W/40W/50W (Pre set 50W)

4-CCT Selectable

5000K | 4000K | 3500K | 3000K

Pre-Set CCT: 4000K

4-CCT Adjustable

3000K - 3500K - 4000K - 5000K

T-Grid Ceiling Installation

Step 1

Turn off the switch

Step 2

Remove the ceiling(s) at appropriate location where the light fixture is to be installed.

After securing the light fixture to the T-bar secure the light fixture to the ceiling with aircraft cable or wires capable of supporting 100lbs. minimum

Step 3

Power leads connection remove screw holding access cover plate and remove the necessary knockout

Step 4

DIMMABLE 0-10V
3-wire connection black, white & green

From power source

Connect cable wires with appropriate relief strain and wire connection (not provided). Make sure ALL wires are tucked in before reinstalling the cover plate.

Wiring Diagram

Step 5