

## **BuzziShield Light**

INSTALLATION MANUAL MODE DE L'EMPLOI 100V-240V/277V







## **Technical info**



**A** The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.


## Excluded








## **BuzziShield Light**


2 PERS. 📽

















BuzziSpace Groeningenlei 141 2550 Antwerp, Kontich Belgium ☎+32 (0)3 846 10 00 ☑ info@buzzi.space % www.buzzi.space

