
BuzziProp LED

INSTALLATION MANUAL MODE DE L'EMPLOI 100V-240V/277V





Technical info













A The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

Excluded





Included





BuzziProp LED


2 PERS.
































BuzziSpace Group NV Italiëlei 8, 2000 Antwerp Belgium ☎+32 (0)3 846 10 00

■ info@buzzi.space

% www.buzzi.space



A-000003378/06 Last update: 04/12/2023