BuzziNest Office


INSTALLATION MANUAL
EU






2 PERS.


Excluded






Included


Red
16x
M8 x 30 mm




Yellow
16x
M8 x 50 mm




Pink
8x
4,8 x 19 mm



Dark Green
8x
M8 x 16 mm




Orange
16x
4 x 16 mm




Purple
4x
4 x 45 mm




Beige
2x
M8 x 25 mm




Beige
4x
M8 x 25 mm





Mint
4x
M8 x 20 mm
5 mm




Burgundy
2x
M5 x 25 mm
3 mm













1x












Height adjustable workspace




Optional foldable seat




1





2




3















4










5







6








7
8x
4,8 x 19 mm
Pink



8
4x
M8 x 30 mm
Red


9




10










11




12











13











14
6 mm


15
6 mm


16





17
4x
M8 x 25 mm
Beige
6 mm



18


19




19 Optional






20



21



22
4x
M8 x 16 mm
Dark
Green


23









24
2x
M5 x 25 mm
Burgundy



25
4x
M8 x 16 mm
Dark Green
2x
M8 x 25 mm
Beige



26
2x
4 x 16 mm
Orange



27
M2
M1
H



28
M2
M1


29



30



31



32


33


34









35






36

No foldable seat **P.32**




Optional foldable seat **P.33**








Continue page 36


Optional foldable seat





2



3
a
b
c
d
e



37
4x
4 x 16 mm
Orange


38
4x
4 x 16 mm
Orange



39

40 2 PERS.







41



!



Change default Settings




Touch and hold logo within 10 seconds after powering up


Default level when in use	60%	30%	60%
Level 5 mins after use	0%	0%	40%
Stand-by level (15 mins after use)	0%	0%	20%

Use factory settings **Cancel** **Save & exit**


Worktop height calibration




Keep pressing down until you hear a beep.




Move Office




1





2





3




4


5
8 mm


6


7

BuzziSpace Group NV
Italiëlei 8, 2000 Antwerp
Belgium
☎ +32 (0)3 846 10 00
info@buzzi.space
www.buzzi.space

Doc nr.: A-0000008131
Last update: 14/04/2025