

Thermal Comfort Features

Thermal Comfort				
Measurement	Location / Description	T01.1: For all spaces except commercial Kitchens	T02.1: For all spaces except commercial Kitchens	T07.1: Humidity Control
1	South Tower Level 5 Open Office -SE	MET	MET	MET
2	South Tower Level 5 Open Office -SW	MET	MET	MET
3	South Tower Level 5 Open Office -NW	MET	MET	MET
4	South Tower Level 5 Open Office -NE	MET	MET	MET
5	South Tower Level 4 Open Office -SE	MET	MET	MET
6	South Tower Level 4 Open Office -W	MET	MET	MET
7	South Tower Level 4 Open Office- NE	MET	MET	MET
8	North Tower Level 2 Open Office -SW	MET	MET	MET
9	North Tower Level 2 Open Office -W	MET	MET	MET
10	North Tower Level 2 Open Office -N	MET	MET	MET

