Installation Manual

1



4PCS

2



Tighten the screws

Screws pre-installed

3



Tighten the screws

Screws pre-installed

4



5



Lower Version



Remove the middle pole
can turn to lower version