



Advanced managerial armchair with upholstered back.

## Seat & Backrests

---

The back is made with a black or white polypropylene frame that supports a thermoformed membrane padded and covered in Chili fabric in the following colors:



470 gr/mtl  
100% post-consumer recycled polyester  
Classe1 - 60.000 +/- cicli Maltindale

Equipped with adjustable lumbar support in nylon or soft polyurethane

The fully upholstered seat, sewn with double side stitching made of cold-foamed polyurethane 5 cm thick.  
The frontal anatomical shape has anti-stress function for the legs.

## Armrests

---

Fixed armrests in die-cast aluminium

Fixed armrests in die-cast aluminium and coated pad

Adjustable 3D armrests in black polypropylene with soft polyurethane pad with chromed aluminium profile

Adjustable 4D armrests in black or white polypropylene with soft polyurethane pad in black with glossy aluminium profile

# That's it Light soft cover

## Mechanism

That's It has two options for the mechanism:



1 - Synchronized tilt adjustment mechanism seat back with anti-shock system lockable in 4 positions adjustable. Elevation and synchron lock of the seat by small levers. Sliding seat (All controls are integrated in the underseat with small levers.) Seat easily removable and replaceable without the use of tools.

2 – Synchron self weight adjustable with levers, synchronized adjustment of the seat back tilt with Anti-shock system lockable in 4 positions. Angle swing backrest 20°. Seat oscillation 6.5°. Seat slider.

The gas column complies with DIN 4550 standard and exceeds the 4th level

## Base

The basis to be associated is usually of three types:

- "TREND" 5-spoke on polished aluminium wheels [d. 680 mm]
- "TREND" 5-spoke on black polypropylene wheels [d. 680 mm]
- "TREND" 5-spoke on white polypropylene wheels [d. 680 mm]

Standard black nylon double tread wheels with 65 mm diameter.



Measures	Seat height	Total height	Width	Depth
cm	42/53	103/115	68/49	68/48-56

## Product's certificate



---

## **Disassemblability**

---

All products have been designed in such a way that they can be disassembled at the end of their useful life, so that their parts and components can be reused, recycled or recovered for energy purposes.

## **Guarantee and safety**

---

QUINTI guarantees that the products will keep their characteristics for 6 years from delivery, save normal wear and provided they are used according to the indications given. QUINTI will replace any product found not to comply with this warranty at no cost, without bearing any other responsibility. The application of the component warranty is excluded; external accessories or materials provided by the buyer and applied to products for the purpose of a customization of the same. For optimal maintenance of the products and to maintain unchanged the characteristics of the materials with which they are made, some simple attentions are required.

All the sessions offered are SAFE according to the provisions of the EU Regulation 2023/988, on general product safety (GPSR), reinforced by UNI EN certifications.

The company is not liable for misuse (Stand up or use products such as ladders and oscillations that could affect the operation and safety of the user. To lift or move the product, grasp firmly on the supporting structure. The product must not be subjected to decentralized loads, is designed to be used in normal standing conditions on 4 legs or on the base).

## **Use & Maintenance**

---

For an optimal maintenance of the products and to maintain unchanged the characteristics of the materials with which they are made, some simple attentions are necessary.

### **THE TEXTILES**

Cleaning: consult the recommendations for maintenance and washing given in the fabric sheet of the color chart. Use: It is recommended to pay attention to the use as it can be torn or cut.

### **THE LEATHERS**

Cleaning: clean with a damp white cloth soaked in water only. Use high-quality leather care products according to the manufacturer's instructions. In case of doubt, test the product on a part hidden from view to verify the result, waiting at least 24 hours for possible problems. Use: remember that the leather is a delicate material therefore it is recommended to take care during use.

### **THE METALS**

Cleaning: both metal surfaces made of steel or aluminium, as well as painted surfaces, must be cleaned with a damp and soft cloth soaked in hot water. For the most stubborn stains, you can dilute liquid neutral soap in water with moderation. Always dry after cleaning with a soft cloth or deer leather. Do not use creams and pastes to clean steel, do not use chlorine, do not use bleach and other aggressive detergents. It is not recommended to use abrasive pastes, scouring pads and sponges that can scratch metal surfaces. Use: be careful of food stains such as coffee, cola, fruit juices that can leave indelible stains on surfaces.