

The use of a scrub-suction machine and/or rotowash, both with immediate water recovery (vacuum extraction), is permitted to maintain/clean a Floorify floor.

When using such devices, the following should be considered:

- Always use a soft scrubbing brush with synthetic fibres, type "Soft PPL 0.3". Bristles that are too hard can lead to damage to the floor and its coating.
- Clean the floor with immediate water recovery. This avoids excess water on the floor, the deposited dirt is immediately absorbed, and the floor is left dry.
- The floor should never be cleaned dry. Always do this in combination with water. Dry cleaning will have an abrasive effect on the floor and there is a real chance that you will damage the topcoat, cause scratches and/or leave an imprint of the brush. It is therefore necessary to wet the floor beforehand where the brush first contacts the floor.
- After cleaning, immediately remove the appliance from the floor or move the appliance to the position where the brush no longer contacts the floor. This will avoid excess water on the floor and/or an imprint of the brush. Do the same with the adjustable water wiper.
- Never leave the appliance idling. This is likely to damage the floor's coating and cause scratches.
- Avoid an abrupt start-up of the rotary brush and ensure a step-by-step build-up of rotation. Risk of damaging the coating and causing scratches.
- The speed of the machine/brush should be set at the lowest setting.

