

# Chevy Nova 1966-67 Headliner Installation Instructions




## Included Parts:

Headliner  
Sail Panels

## Tools Required for Installation:



Plastic Trim Tools  
Phillips Screwdriver  
Spring Clamps  
Needle, or Tack



**Step 1.** Remove the old headliner including, sun visors, rear view mirror, and dome light.

**NOTE: Please keep all hardware as it will be used for the new headliner installation.**



**Step 2.** Roll all four windows down in the vehicle.



**Step 3.** Starting from the drivers side, slide the headliner into the vehicle. Make sure the headliner is over the top of the dash board and steering wheel.

**Step 4.** Once the headliner is in the vehicle have a helper to push the headliner onto the roof.

**Step 5.** Line up the headliner where it fits against the front top of the windshield and the back of the rear glass. Make sure the left and right sides are even with the top of the door openings.



**Step 6.** Using 4 spring clamps, clamp the headliner to the roof of the vehicle. Put 1 clamp in the front top of the door opening for the driver side and 1 clamp for the passenger side. Put 1 spring clamp towards the back top of the door opening for the driver side and 1 clamp for the passenger side.

**NOTE: The 4 spring clamps will keep the headliner from falling and allow you to adjust the position if needed**

# Chevy Nova 1966-67 Headliner Installation Instructions






## Included Parts:


Headliner  
Sail Panels

## Tools Required for Installation:

Plastic Trim Tools  
Phillips Screwdriver  
Spring Clamps  
Needle, or Tack




**Step 7.** Install the original windlace (pinch molding) starting with number 1 and ending with number 4.



**Step 8.** Snap in the sail panels on the left and right rear of the vehicle.

**Step 10.** Reinstall the sunvisors, and Dome light.



**Step 9.** Using a needle or tack locate the 3 screw holes to mount the left and right visors.