

WWW.ENVISIONLEDLIGHTING.COM

LED Linear High Bay Installation Instruction

Cautions:

- 1. Do not use any electric generator to test the LED light.
- 2. Please abide by related country, regional and local law and regulations when installing this fixture.
- 3. Please turn off the power before installation or maintenance.
- 4. Proper earth grounding is required to ensure safety.

Notice:

- 11. To avoid possibility of electrical shock or fire, the installation personnel must have professional electric knowledge.
- 2. Please wear gloves to avoid injury before installation.
- 3. If any smoke or spark of the wire happened, please turn off the power immediately and notify relevant personnel.
- 4. Please use listed strain relief bushing when connecting the supply cord to the outlet box.

Attention:

- 1. Please check if there is any damage during shipping. If so, please contact manufacturer timely.
- 2. Please read the installation instruction carefully to check whether all the accessories are complete, After confirmation, install the fixture according to installation steps.

Wiring Diagram & Instruction:

- 3 dimming functions are available in this high bay light:
- 1. Constant current can be achieved by 0-10V dimming;
- 2. PWM signal dimming;
- 3. Variation of resistance unit dimming.

Description:	
This product is 0-10V dimming, below	
dimmers are recommened:	
Brand	Model
LUTRON	DVSTV-453

Wiring Instruction

L:B**l**ack, N:White.

: Green/Yellow

DIM +

DIM -

(As for the wire color of DIM+ and DIM-, pls check the light label.)

Please choose the appropriate dimming way according to your needs. You can also choose not to use this function.

*The product can not be connected to a dimming device when it's equipped with Motion Sensor.

Three Installation: Chain/Cable linstallation, 3/4"NPT Installation, Surface Mounting (Please choose the most suitable installation method for the purchased product as per your needs)

A.Hanging Installation:

Step1. Hook up the chain; (Figure 1)

Step2.Connect the chain with fixture; (Figure 1)

Step3. Fix the chain on the rail, adjust the chain length as per need; (Figure 1)

Step4.After fixed , choose suitable wiring knock out, and connect the wires according to local standard and code.

Step5.The light-emiiting modules can be rotatable, and the maximum angle of outward rotation is 135°. (Figure 2)




Figure 2

B.3/4"NPT Installation:


Step1. Mount the bracket on 3/4"NPT; (Figure 3)

Step2. Lock fixture on the bracket; (Figure 4)

Step3. Connect the wires according to local standard and code;

Step4. Lock side brackets with screwdriver; (Figure 5)

Step5. After installation, rotate the light-emitting modules to get the best lighting angle you want (the maximum angle of outward rotation is 135°).






Figure 3

Figure 4

Figure 5

C.Surface Mounting: (If this bracket is used for the fixture, backup driver solution cannot be chosen)

Step1. Mount the bracket on the rail or ceiling; (Figure 6)

Step2. Assemble the lamp on the bracket and fix it with screws; (Figure 7)

Step3. After fixed, choose suitable wiring knock out and connect the wires according to local standard and code;

Step4. After installation, rotate the light-emitting modules to get the best lighting angle you want (the maximum angle of outward rotation is 135°).





Figure 6

Figure 7

Extra Accessory Option Installation: 1:Wire Guard, 2:Motion Sensor / PIR Sensor,3: Backup driver

1.Wire Guard: (Purchase the correct size of wire guard from manufacturer) Step1. Clamp the iron pieces on both ends of the wire guard into the plug of the light-emitting modules, push them to the end, and tighten them with screws. (Figure 8)





Figure 8

2-1. Motion Sensor / PIR Sensor: (Both sensor are with same installation)

Step1. Open the face cover with screwdriver; (Figure 9)

Step2. Knock out the side cover, mount the sensor on the side, connect the wires accofing to the sensor instruction; (Figure 10)

Step3. Mount the face cover back with screwdriver. (Figure 11)



2-2. DC Motion Sensor / PIR Sensor (Both sensors are with the same installation method)

Step1. Use a screwdriver to remove the 1/2 plug from the sensor; (Figure 12)

Step2. Twist-lock the DC sensor to the base to make it work properly, use a remote control to adjust the working mode as per demand. (Figure 13)




Figure 12 Figure 13

