
# **BuzziNest Pod**

INSTALLATION MANUAL US





# **Content**

Foreword	3
Fire Safety.	
Electrical Safety	
Installation, maintenance and disassembly	
Use	
Markings	
Wiring Diagram	11
Assembly instructions	
Move Pod	

# **Foreword**

# **Safety Instructions**

# Important safety and product instructions

### **Preface**

This instruction manual shows the necessary information for the installation of the product. Make sure that everyone involved in the installation has read and understands the contents of the installation and the safety instructions.

Review the assembly instructions to confirm that the appropriate critical components and accessories are being used with the furnishing. These prefabricated modules and assemblies are intended for installation rearrangement and inspection in accessible locations in accordance with Article 604 of the NEC. AHJs should be consulted prior to installation.



A SAVE THESE INSTRUCTIONS

### **Product Information**

The information in this manual is valid at the time of publication and corresponds to the product at the time of delivery.

### Intended use

BuzziNest Pod is intended for short term indoor commercial and household use by four (4) persons at a time.

WARNING: To reduce the risk of burns, fire, electric shock or injury to persons: Use this product only for its intended use as described in the user instructions. Do not use attachments not recommended by the manufacturer

# **Fire Safety**



### **WARNING!**

To reduce the risk of burns, fire, electric shock or injury to persons, obey the following:



In case of a fire inside the booth, disconnect the power cord when it's safe to do so.

The power cable serves as a power cut device for pluggable equipment.

The power outlet must be near the equipment and easily accessible.

Fire and safety devices like sprinklers or alarms can be installed in the booth (separate instructions on demand).

The need for fire and safety devices in the booth shall always be determined by the applicable local authorities.

# **Electrical Safety**

Input for the electrical system: 120V AC 15A 50-60Hz The maximum load for the electrical system is 15A.



### DANGER!

# To reduce the risk electric shock, obey the following:



In non-hardwired products:

Always unplug this furnishing from the electrical outlet before cleaning or servicing.

Unplug from outlet before putting on or taking off parts Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged.

Connect this furnishing to a properly grounded outlet only In case of a fire inside the booth, disconnect the power cord when it's safe to do so.

In hardwired products:

Always disconnect this furnishing from the electricity network before disassembly, cleaning or servicing.



### **WARNING!**

To reduce the risk of burns, fire, electric shock or injury to persons, obey the following:



Connect the power cord to a properly grounded outlet only.



Keep the power cord of the product away from the heated surfaces.



Do not use the BuzziNest Booth if you notice any defects or damage to the electrical equipment.



Do not connect any extension cords to the power outlet(s) of the product.

# Installation, maintenance and disassembly



# **WARNING!**


To reduce the risk of burns, fire, electric shock or injury to persons, obey the following:



Use cut resistant safety gloves during the installation, maintenance os disassembly of the product.



Use Steel toed safety boots during the installation, maintenance or disassembly of the product.



## Use

The maximum load for the BuzziNest Pod Table is 110 lbs (50 kg) The maximum load for the BuzziNest Cube is 300 lbs (136 kg)



# **WARNING!**

To reduce the risk of burns, fire, electric shock or injury to persons, obey the following:



Read and follow closely the instructions before using the product.



Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.



Keep children away from extended foor support (or other simular parts).



The air inside the product is extracted from the surrounding area, if this surrounding area is in anyway hazardous, do not use the product.



Do not use the product in case of a non-working ventilation.



Do not use the product in case of blocked ventilation channels, make sure the ventilations channels are kept open and free from any dust fluff, hair and such.




Never operate this furnishing if it has any defects in the electrical equipment, if it is not working properly, if it has been dropped or damaged. disconnect this furnishing from the electricity network and contact your dealer.



# Markings

# **BuzziNest Pod**



# Label

### **Label Text**



Product/ Produit: BuzziNest Pod Input/Entrée: 120V AC 15A 50-60Hz Manufacturer/Fabricant: BuzziSpace

Web: www.buzzi.space Email: info@buzzi.space

Made in Lithuania / Fabriqué en Lituanie Evaluated to ASTM E84, smoke developed index over 450. / Évalué selon ASTM E84, indice de fumée développé supérieur à 450.

SN/N° de série: . MANUFACTURE DATE / DATE DE FABRICATION: MM/YYYY

3.

WARNING

Risk of fire and shock! Use Only SJT type 14 AWG cord. See installation manual for instruction on how to hard wire to mains supply. Kit Code: 881

# **AVERTISSEMENT**


Risque d'incendie et d'électrocution! Utilisez uniquement un cordon de type SJT 14 AWG. Consultez le manuel d'installation pour savoir comment se connecter au réseau électrique. Code du kit: 881

4.

This furnishing has not been evaluated for flammability or cigarette ignition resistance.

L'inflammabilité ou la résistance à l'allumage d'une cigarette n'a pas été évaluée pour cette garniture.

# **BuzziNest Booth with optional table**



### Label

### **Label Text**



Product/ Produit: BuzziNest Pod Input/Entrée: 120V AC 15A 50-60Hz Manufacturer/Fabricant: BuzziSpace

Web: www.buzzi.space Email: info@buzzi.space

Made in Lithuania / Fabriqué en Lituanie Evaluated to ASTM E84, smoke developed index over 450. / Évalué selon ASTM E84, indice de

fumée développé supérieur à 450.

SN/N° de série: . MANUFACTURE DATE / DATE DE FABRICATION: MM/YYYY

3.

WARNING

Risk of fire and shock! Use Only SJT type 14 AWG cord. See installation manual for instruction on how to hard wire to mains supply. Kit Code: 881

**AVERTISSEMENT** 

Risque d'incendie et d'électrocution! Utilisez uniquement un cordon de type SJT 14 AWG. Consultez le manuel d'installation pour savoir comment se connecter au réseau électrique. Code du kit: 881

WARNING Risk of injury The maximum load for the BuzziNest Pod Table is 110 lbs (50kg)

L' AVERTISSEMENT Risque de blessure Poids maximal pour BuzziNest Pod Table est de 110 lbs (50 kg)

5. Max. 14A


Max. 14A

6.

This furnishing has not been evaluated for flammability or cigarette ignition resistance.

L'inflammabilité ou la résistance à l'allumage d'une cigarette n'a pas été évaluée pour cette garniture.

# **Wiring Diagram**




**Note:** Only a certified electrician compliant with all local rules and regulations can install the same metal conduit cable.

# **BuzziNest Pod**


# 2 PERS. 👺





# **Excluded**




# Included










# No Table





# **Optional Table and electrification**


















































# 





# 





# 


























## **Optional Hardwired**











Fit conduit to hard wired plate. (conduit not provided)


Make relevant wire splices.


Push wires into enclosure.


Secure with bolts.








































No table P.56




Optional Table + Electrification

P.61




## No table





**4**x


4 x 16 mm


Orange













The cable must be installed so there is no tripping hazard.


Adequate cable restraints must be used to secure the connection to the mains.


Requires certified electrician compliant with local AHJ regulations to install hard wired conduit cable.


## Optional Table + Electrification










































## 15 a












The cable must be installed so there is no tripping hazard.


Adequate cable restraints must be used to secure the connection to the mains.


Requires certified electrician compliant with local AHJ regulations to install hard wired conduit cable.




















BuzziSpace Group NV Italiëlei 8, 2000 Antwerp Belgium ≅ +32 (0)3 846 10 00

info@buzzi.space www.buzzi.space



Doc nr.: A-0000007391/05 Last update: 30/11/2023